After Inflation-Before HyperFlex Injection WATER **HYPERFLEX** Flow Through Packer Nitrogen Fill Line Shut Off Valve Water

After HyperFlex Injection

- 1. Insert Packer into Bore
- 2. Inflate & close Nitrogen valve
- 3. Close water shut off
- 4. Connect injection line
- 5. Open water shut off valve
- 6. Pump to pressure rise, sealing
- 7. Disconnect injection line

Orphan Bore Hole Sealing



HyperFlex Injection Line

PO Box 1178 Mars, Pa 16046 866-625-4550 www.sealguardinc.com