


# High Pressure Seal Injection For Larger General Repairs Plan View of Seal




## Instructions:

- 1) Drill and Set Packers around Perimeter of Seal (Roof, Rib & Floor)
- 2) Inject HyperFlex until a show of material is seen around the Seal Edges or until pressure increase

① Extensions set around Seal Perimeter (Roof, Rib & Floor)

② Reacted urethane at Perimeter of Seal

 =HyperFlex



**Mine Seal Repair**

**SealGuardinc.** 

PO Box 1178  
Mars, Pa 16046  
866-625-4550  
[www.sealguardinc.com](http://www.sealguardinc.com)